

441, 442 Anchorman Manual

Item	Part No.	Description	Quantity
1A	60615RC6	Gipsy RC 10mm	1
1B	60615RC7	Gipsy RC 8mm	1
2	441-002	Baseplate C/Pd	1
4	441-004A	Gipsy pawl assembly-S5668	1
6	445-013	Nameplate S5678	1
7	400-017	Shoulder pin	1
8	441-008	Plain bush	1
10	441-010	Washer nylonic 7814	1
11	6044111	Pawl & spring set	Set
12	6044111	Pawl & spring set	Set
13	441-013	Slotscrew 18/8 SS RCSK M6	1
14	441-014	Form A washer 18/8 SS M20	1
20	441-020	Drum C/Pd	1
21	6044544	Clutch nut	1
22	441-022	Screw 18/8 SS SKTCAP M6	1
23	441-023	Hole plug	1
30	6044900	Fleming retrofit kit	Set
31	6044570	Fleming	1
32	445-074	Screw 18/8 SS CHD M4 12mm	1
33	446-077	Pry out hole plug	1
D17	441-017	Distance piece S5599-02	1
D18	60441D18	Gipsy carrier D18 GD	1
D19	441-019	Drum cap C/Pd	1
G119	446-142	Gipsy cap C/Pltd	1
G17	442-017	Distance piece S5599-2	1
G18	60442G18	Gipsy carrier G18 G	1
G19	446-142	Gipsy cap C/Pltd	1

